


QUICK
START
GUIDE

TUNE 720 BT


HARMAN

WHAT'S
IN THE
BOX




SCAN ME

APP

 JBL HEADPHONES

GET EVEN MORE CONTROL AND PERSONALIZATION OF YOUR LISTENING EXPERIENCE WITH THIS FREE APP.

 GET IT ON Google Play

 Download on the App Store


(FOR CHINA ONLY)


POWER
ON &
CONNECT


HOLD (2s)

OTHERS

ANDROID™ 6.0+

WINDOWS 10 V1803+


MICROSOFT SWIFT PAIR

* TO ENTER PAIRING MODE AGAIN, POWER OFF AND HOLD  FOR 5 SECONDS.

CHOOSE "JBL TUNE720BT" TO CONNECT

Fast Pair

MULTI-POINT CONNECTION

1

2

3


L R
(MAXIMUM 2 DEVICES)


PRESS × 2

CONTROLS


L R









PRESS × 1
HOLD (2s)




* ENABLE ADVANCE CONTROLS BY CONNECTING YOUR JBL TUNE720BT TO JBL HEADPHONES APP.

WIRED LISTENING MODE



L R



DO MORE WITH THE APP



CHARGING


L R

CHARGE

5MIN  = 3HR 

2HR 



FACTORY RESET


L R




HOLD (5s)

LED BEHAVIORS

 LOW BATTERY

 CHARGING

 FULLY CHARGED



R

 POWER ON

 BT CONNECTING

 BT CONNECTED

 BT NOT CONNECTED


R

TECH SPEC

Model:

Driver size:

Power supply:

Weight:

Battery type:

Charging time:

Music playtime with BT on:

Talk time:

Frequency response:

Impedance:

Sensitivity:

TUNE720BT

40 mm/ 1.57" Dynamic Driver

5V --- 1A

220 g/ 0.485 lbs

Lithium-ion Battery (500 mAh/ 3.7V)

2 hrs from empty

Up to 76 hrs

Up to 45 hrs

20 Hz – 20 kHz

32 ohm

101 dB SPL@1 kHz

Maximum SPL:

Microphone sensitivity:

Bluetooth version:

Bluetooth profile version:

Bluetooth transmitter frequency range:

Bluetooth transmitter power:

Bluetooth transmitter modulation:

Maximum operation temperature:

95 dB

-40 dBV/Pa@1 kHz

5.3

AZDP v1.3.2, AVRCP v1.6.2, HFP v1.7.2

2.400 GHz - 2.4835 GHz

≤ 10 dBm (EIRP)

GFSK, π/4-DQPSK, 8-DPSK

45 °C

